


Parallel printer Connections.



signal	25 Way 'D'	36 Way Centronic
- strobe	1	2
d0	2	2
d1	3	3
d2	4	4
d3	5	5
d4	6	6
d5	7	7
d6	8	8
d7	9	9
- ack	10	10
busy	11	11
pe	12	12
slct	13	13
- autofp	14	14
- error	15	32
- init	16	31
- slct in	17	36
ground	18-25	16,19-30,33